

FITTING INSTALLATION GUIDE FOR ELLIPTICAL LEG TANKS

Norwesco elliptical leg tanks come standard with a bulkhead fitting installed or the tank may be ordered without a fitting. For instances when you would like to install a smaller or larger bulkhead fitting, would like to install a bolted fitting or would like to install additional fittings, please refer to this guide.

The maximum fitting sizes shown for elliptical leg tanks are based on installing the fitting in the standard flat area at either end of the tank. Please contact a Norwesco distributor or Norwesco Customer Service if you would like to install a fitting in any other location.

Gallon Capacity	Maximum Bulkhead Fitting Size	Maximum Bolted Fitting Size
135	1-1/4"	1"
235	2"	2"
335	2"	2"
535	2"	2"
1035	3"	3"
1235	2"	2"
1335	3"	3"
1635	3"	3"
2035	3"	3"
2635	4"	4"
2650	4"	4"
3135	4"	4"
3250	4"	4"
4035	4"	4"

Revised 4/7/19